




MIDI KEYBOARD

AXIS-1

Owner's Manual



RADIO AND TELEVISION INTERFERENCE

Warning – This equipment has been verified to comply with the limits for a Class B computing device, pursuant to Subpart J, of Part 15, of FCC Rules. Operation with non-certified or non-verified equipment is likely to result in interference to radio and TV reception.

The equipment described in this manual generates and uses radio-frequency energy. If it is not installed and used properly, that is, in strict accordance with our instructions, it may cause interference with radio and television reception.

This equipment has been tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J, of Part 15, of FCC Rules. These rules are designed to provide reasonable protection against such a interference in a residential installation.

However, there is no guarantee that the interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by the following measure:

- Disconnect other devices and their input/output cables one at a time. If the interference stops, it is caused by either the other device or its I/O cable. These devices usually require Roland designated shielded I/O cables. For Roland devices, you can obtain the proper shielded cable from your dealer. For non Roland devices, contact the manufacturer or dealer for assistance.

If your equipment does cause interference to radio or television reception, you can try to correct the interference by using one or more of the following measures:

- Turn the TV or radio antenna until the interferences stops.
- Move the equipment to one side or the other of the TV or radio.
- Move the equipment farther away from the TV or radio.
- Plug the equipment into an outlet that is on a different circuit than the TV or radio. (That is, make certain the equipment and the radio or television set are on circuits controlled by different circuit breakers or fuses.)
- Consider installing a rooftop television antenna with coaxial cable lead-in between the antenna and TV.

If necessary, you should consult your dealer or an experienced radio/television technician for additional suggestions. You may find helpful the following booklet prepared by the Federal Communications Commission:

"How to Identify and Resolve Radio-TV Interference Problems"

This booklet is available from the U.S. Government Printing Office, Washington, D.C., 20402, Stock No. 004-000-00345-4.


Contents

1	Panel Description	3	b. Play Made and Write Mode	20
2	Connection	6	c. Changing the functions of Wheels	21
3	Operation	7	d. Changing the functions of Buttons	22
1	Using Wheels and Buttons that have fixed functions	7	1) Control Change Numbers (64 to 95)	23
a.	MIDI Channel Setting	8	2) Modulation	23
b.	Setting a Program Change number	9	3) Octave Up/Down	23
1)	Setting a program change number (1)	10	4) Chord Memory	23
2)	Setting a program change number (2)	12	5) Increment/Decrement	23
c.	Key Transpose	13	6) Patch Chain	23
d.	Pitch Bender	15	7) Latch/Unlatch of the buttons	26
e.	Other Functions	15	3 Functions	28
1)	Key Velocity (Dynamics)	15	a. How to get the Display show the current condition	28
2)	After Touch	15	b. How to turn on or off the function	28
3)	MIDI Out Indicator	15	c. Explanation on the Functions	28
2	Using the Wheels and Buttons which have flexible functions	16	1) After Touch	28
a.	How to Initialize	17	2) Touch Hold	29
1)	Modulation Wheel	18	3) Poly/Mono	29
2)	Master Volume Wheel	18	4) OMNI ON/OFF	29
3)	Modulation Button	18	5) Tune Request	29
4)	Octave Up Button	18	4 Appendix Table	30
5)	Chord Memory Button	18	5 Specifications	32
6)	Remote Switch Pedal (Hold Pedal)	18	• MIDI Implementation	

To benefit all the advantages of the Axis, read the separate volume "MIDI", then this owner's manual.


1 Panel Description

Control Unit



In this owner's manual, each key of the keyboard is named as shown above.

Power Supply Unit



Axis is able to send various MIDI messages, but if the receiver cannot receive the message, the corresponding function is not obtained.

The Buttons 1, 2, 3, the Wheels 6, 7 and the Pedal 17 have flexible functions.

Important Notes

Power Supply

- Make sure that the line voltage system in your country meets the one shown in the name plate of the unit.
- Do not turn the units on before setting them up.
- This unit might not operate properly, if turned on immediately after turned off. If this happens, turn it off, then turn it on again in a few seconds.

Location

- Operating this unit near a neon or fluorescent lamp may cause noise interference. If so, change the angle or position of the Axis.
- Avoid using this unit in extreme heat or humidity or where it may be affected by dust or direct sunlight. Otherwise deformation or other trouble may occur.

Cleaning

- Use a soft cloth and clean only with a mild detergent.
- Do not use solvent such as paint thinner.

Outline of Axis


Axis is a keyboard designed to control MIDI sound module by sending various MIDI messages. Actually, the Axis is ready to send almost all MIDI messages that are necessary to control the sound module connected to it. The necessary MIDI messages differ depending on the sound module used. If all the buttons and wheels that control those messages were provided on the Axis, they would be so many, causing complication. The Axis, however, has a unique feature that resolve this problem; some wheels and buttons are flexible for several functions. For instance, a certain wheel can behave as a modulation control, volume control or portamento time control, etc.

Each Key on the keyboard is assigned to do several jobs, and one of the jobs is to change the functions of the buttons and wheels. That is why the Axis has the minimum numbers of wheels and buttons for the maximum performance control effects.


Moreover, the function you have set is retained even if the Axis is turned off.

This 45-key, light-weighted keyboard can be easily slid around your neck, and it features the After Touch and Key Velocity sensitivities.

Flexible Wheels and Buttons



2 Connection



- For connecting the Control Unit and the Power Supply Unit, use the supplied connection cable. Also, for setting up MIDI device, use the supplied MIDI cable MSC-50.


- First make all connections, then turn the connected Sound Module on, and finally the Power Supply Unit.

3 Operation

If properly set up, the Axis can always be ready to be played. Some of the wheels and buttons on the Axis have several functions, and you can select any of the functions by a simple operation. But to avoid causing any confusion, first initialize the Axis, so that all the wheels and buttons choose the functions as marked on the body. (We call this **Standard Setting**.)

1 Using Wheels and Buttons which have fixed functions

The wheels and buttons that have fixed functions



a. MIDI Channel Setting

It is necessary to match the MIDI Channel number of the Axis and the external MIDI device. Use the MIDI Channel Button ❶ and a key on the keyboard to set a MIDI Channel of the Axis.


Operation

- ❶ Push the MIDI Channel Button ❶.

The Display ❷ shows the current MIDI Channel number.


- ❷ As shown below, the Keys from E_0 to F_7 correspond to the MIDI Channel 1 to 16. Push the relevant key while holding the MIDI Channel Button ❶ down.

The MIDI Channel you have set is shown in the Display.




e.g.) To set MIDI Channel 5

While holding the MIDI Channel Button ❶, push the B_0 Key.



b. Setting a Program Change Number

Program Change is a MIDI message that can change tone colors in the external sound module. The Axis can send 0 to 119 program change numbers. To assign a number, select a block A, B, C, D or E with the black key, then push a white key from E₀ to G₃.




Key	Block A		Block B		Block C		Block D		Block E	
	Program Change	Display ●	Program Change	Display ●	Program Change	Display ●	Program Change	Display ●	Program Change	Display ●
E ₀	0	11	24	41	48	71	72	21	96	51
F ₀	1	12	25	42	49	72	73	22	97	52
G ₀	2	13	26	43	50	73	74	23	98	53
A ₀	3	14	27	44	51	74	75	24	99	54
B ₀	4	15	28	45	52	75	76	25	100	55
C ₁	5	16	29	46	53	76	77	26	101	56
D ₁	6	17	30	47	54	77	78	27	102	57
E ₁	7	18	31	48	55	78	79	28	103	58
F ₁	8	21	32	51	56	81	80	31	104	61
G ₁	9	22	33	52	57	82	81	32	105	62
A ₁	10	23	34	53	58	83	82	33	106	63
B ₁	11	24	35	54	59	84	83	34	107	64
C ₂	12	25	36	55	60	85	84	35	108	65
D ₂	13	26	37	56	61	86	85	36	109	66
E ₂	14	27	38	57	62	87	86	37	110	67
F ₂	15	28	39	58	63	88	87	38	111	68
G ₂	16	31	40	61	64	91	88	41	112	71
A ₂	17	32	41	62	65	92	89	42	113	72
B ₂	18	33	42	63	66	93	90	43	114	73
C ₃	19	34	43	64	67	94	91	44	115	74
D ₃	20	35	44	65	68	95	92	45	116	75
E ₃	21	36	45	66	69	96	93	46	117	76
F ₃	22	37	46	67	70	97	94	47	118	77
G ₃	23	38	47	68	71	98	95	48	119	78

You can even hear the corresponding tone color while changing the program change numbers. (This is explained in “(2) Setting a Program Change Number (2)” on Page 12)

1) Setting a Program Change Number (1)

- ① While holding the Program Change Button ③ down, select a Block you like by using a black key.




- ② While still holding the Program Change Button ③, push the white key that corresponds to the program change number you want.


The program change number you have set is shown in the Display. If the program change number you wish to set is within the same block of the current one, skip the step ①.

e.g.) Setting program change number 9

① Program change number 9 is in the Block A. So push the F# key while holding the Program Change Button ③.



② Program change number 9 corresponds to the G₁ key. So, push the G₁ key while still holding the Program Change Button ③.



The Display ⑩ shows 22

The number shown in the Display does not correspond to the actual program change number. (See page 7 of "MIDI") That is, you need to translate each number with the aid of the table on page 9.

It may be a good idea to collect your favourite tone colors in the same block in the sequence you like. In this way, you can call those tone colors without changing the Blocks.


2) Setting Program Change Number «2»

In this method, as you change the program change number, you can hear the corresponding tone color.

Operation

① While playing a key (or chord), hold down the Program Change Button ③, then release the key (or keys).

② While still holding the Program Change Button ③, push a relevant key for the program change number you want. When you push the key, the corresponding tone color will be heard in the pitch of the key you played in the step ①.



c. Key Transpose


The Axis allows transposition within 2 octaves upper and an octave down in semitone steps.

Operation

① Push the Key Transpose Button ②.

② While still holding the Key Transpose Button ②, press the key you wish to transpose to from C₂ key.

The Display shows the current condition (C₂ Key).



If the Display shows the abbreviation* of the new key, the transposition is done.

* C₂ to B₂ : C ~ b

C₁ to B₁ : -C ~ -b

C₃ to B₃ : -C ~ -b

C₄ : -C


: . e.g. C₄# : .C

Key Transpose Display ②		
	-E	
	-F	F
	-G	G
	-A	A
	-b	
	-C	C
	-d	d
	-E	E
	-F	F
	-G	G
	-A	A
	-b	
	C	C
	d	d
	E	
	F	F
	G	G
	A	A
	b	
	-C	C
	-d	d
	-E	
	-F	F
	-G	G
	-A	A
	-b	
	-C	

e.g.) To transpose an octave up from C₂

① While holding the Key Transpose Button ② down, push the C₃ key.

When the Display shows , transposition is completed.




- Play a chord, and without releasing the keys, press the Transpose Button ②. Then release the keys, without releasing the button ②, and play with one finger. Now, the chord transposed according to the key you are playing will be heard. In this way, you can enjoy chord playing using only one finger.

To return to the normal playing condition, release the button ②. At this stage, however, the transposition, is not cancelled, that is, the Axis is transposed to the key pressed last.

d. Pitch Bender 5

The Up and Down positions give the pitch bend effect of two extremes, highest and lowest,

Normally, the maximum effect of the pitch bend is adjusted by the sound module.



e. Other Functions

1) Key Velocity (Dynamics)

The Axis can send Key Velocity message depending on how hard you attack the key.

The sensitivity of the Key Velocity is adjusted by the connected sound module.

2) After Touch

The Axis sends After Touch message depending on how hard you press the key after playing a key in a normal manner.



The sensitivity of the After Touch is adjusted by the connected sound module.

3) MIDI Out Indicator

This indicator flashes when the Axis is properly set up, showing that MIDI message is being sent.

2 Using the Wheels and Buttons which have flexible functions.

Each of the wheels and buttons shown below has several functions which you can choose depending what you want from the Axis.



16 Remote Switch Pedal

Before experimenting what the functions each wheel and button has, let's initialize the Axis, so that those wheels and buttons will be set to what we call **Standard Setting**.

《Note》


It is not possible to set more than one button or wheel to the same functions.

a. How to Initialize

① Turn the Axis on, then check if the Power Indicator ⑮ lights, and the MIDI Out Indicator ⑰ flashes.

② While holding the Function Button ① down, press the F♯, C♯ and D♯ keys at the same time.

The Display will respond with , then when you release both your hands. This means that initialization is completed.



Now, the Axis is initialized, and each button and wheel has the Standard Setting. (See the following Standard Setting or the appendix table 1.) The Standard Setting is not cancelled even after the Axis is turned off.

*** When the Display shows , the Standard Setting is erased for some reason. If this happens, be sure to initialize the unit.**

*** If is often indicated, contact your local Roland dealer, as the battery replacement may be required. The battery is supposed to last about 5 years, but the first battery replacement may be required before 5 years.**

Standard Setting

1) Modulation Wheel ⑥

Rotating this toward MAX will deepen the modulation.

The maximum effect of the modulation can be adjusted by the connected sound module.

2) Master Volume Wheel ⑦

Rotating this toward MAX will increase the volume.

3) Modulation Button ④

While this button is being held down, the modulation is turned on.

The maximum effect of the modulation can be adjusted by the connected sound module.

4) Octave Up Button ⑧



Press this button to turn the Octave Up function on, and press it again to turn it off. When it is on, the Octave Up Indicator ⑩ lights up and an octave is transposed up.

5) Chord Memory Button ⑨

This button can be used to record a chord data (Page 19) and enjoy chord playing by using a single key. Each time you press this button, it is alternately turned on and off. When on, the Chord Memory Indicator ⑪ lights up and the Display shows cd.

6) Remote Switch Pedal (Hold Pedal) ⑰

While holding this pedal down, the Hold Indicator ⑫ is lighted, the Hold function turned on.




How to record a chord data

- ① While holding the Function Button **1**, press the G \sharp and A \sharp at the same time.

The Display shows flashing **cd**, showing that the Axis is ready to accept chord data.



- ② Play the chord to be recorded, and release the keys, and recording is done.



* Relation between the recorded chord and actual chords you hear



When C $_2$ Key is played, the actual chord you hear is exactly in the same pitch as the recorded one.


* The recorded chord data is retained even after the Axis is turned off, but will be cleared by initialization.


b. Play Mode and Write Mode

When you play the Axis or to initialize it, it should be in the Play mode. But to change the functions of the flexible wheels and buttons, the Axis should be turned to the Write mode.

How to turn the Axis from the Play to Write mode

While holding the Function Button ❶ down, press the C \sharp and D \sharp keys at the same time.



The Display will respond with flashing , showing that it is now in the Write mode. Take the exactly same operation to return to the Play mode.

Flashing  always means that the Axis is in the Write mode.

c. Changing the functions of wheels

By using the MIDI Control Change numbers from 0 to 31, the two flexible wheels can be set to have the functions you like.

*** Control Change messages include performance control messages such as Vibrato, Hold, Portamento, etc., except for the key message. Each function of the wheel or button has corresponding control change number which can be used to set the function. (wheel: 0 to 31, Button: 64 to 95.)**


*** Some MIDI devices used as sound modules of the Axis have different assignments of the control change numbers. Refer to the owner's manual of each device. And if you have any question about it, contact the manufacturer or the distributor.**

At the moment, the following control change numbers are used to change the functions of the two wheels.

- 1 : Modulation**
- 2 : Breath Controller**
- 4 : Foot Controller**
- 5 : Portament**
- 6 : Data Entry**
- 7 : Total Volume**
- 31: Pitch Bender Sensitivity**

Operation

- ① Turn the Axis to the Write mode as explained on page 20.
- ② Rotate the relevant wheel to MIN, then to MAX.



The Display shows the current control change number.

- ③ Push the key which corresponds to the desired control change number.

The Display shows the new control change number.

Control Change Number	
0	
1	2
3	4
5	6
7	
8	9
10	11
12	
13	14
15	16
17	18
19	
20	21
22	23
24	
25	26
27	28
29	30
31	

- ④ Rotate the wheel to the MIN.

The Display will return to the flashing uu

- ⑤ Return the Axis to the Play mode. (If you wish to continue to operate in the Write mode, remain in the Write mode.)

*** In the Standard Setting, the wheel ⑥ is set to Modulation (Control change number 1), and the wheel ⑦ to the Volume (Control change number 7).**

d. Changing the functions of Buttons

The three buttons on the Axis can have different functions as follows by using corresponding keys.

- **Functions Selected by MIDI Control Change numbers (e.g. Hold and Portamento)**
- **Modulation**
- **Octave UP**
- **Octave Down**
- **Chord Memory**
- **Program Increment**
- **Program Decrement**
- **Patch Chain**

Any of the above functions can be assigned by using a key. The Display shows the control change number assigned, and the abbreviation of the other function. This, however, is seen only while the button is held down, and releasing the button will change to Write mode display.

Operation

① Change to the Write mode as explained in "b. Play Mode and Write Mode" on page 20.

② Push the relevant button.

The Display shows the function currently selected, either in number or abbreviation.

③ While still holding the button down, push the key corresponding to the desired function.

		Control Change Number	
		64	
		65	66
		67	68
		69	70
		71	
		72	73
		74	75
		76	
		77	78
		79	80
		81	82
		83	
		84	85
		86	87
		88	
		89	90
		91	92
		93	94
		95	
			Modulation (Rise Time Fast)
			Modulation (Rise Time Slow)
			Octave Down
			Octave UP
			Chord Memory
			Program Increment
			Program Decrement
			Patch Chain

The Display shows the new function.

④ Return the Axis to the Play mode.

1) Control Change Numbers (64 to 95)

At the moment, the following Control Change numbers are available.

64 : Hold or Damper Pedal
65 : Portamento
66 : Sostenuto
67 : Soft Pedal

2) Modulation (C₃, D₃)

When this function is assigned to one of the flexible buttons, that button can select fast or slow rise time of the wheel's modulation effect.

The Display will show the selected rise time, fast **F5**, or slow **SL**.

3) Octave Up (F₃)/Down (E₃)

When this function is assigned to one of the flexible buttons, that button can select transpositions either one octave upper or down.

The display **OU** means Octave Up and **OD** means Octave down.

4) Chord Memory (G₃)

When this function is assigned to one of the flexible buttons, that button can turn on or off the Chord memory function. (See page 19 for the details of Chord Memory function.)

When the Chord Memory is turned on, the Display will show **CD**.

5) Increment (A₃)/Decrement (B₃)

When this function is assigned to one of the flexible buttons, that button can increment or decrement the current program change number.

The Display will show Program Increment **P_↑** or Decrement **P_↓**.

6) Patch Chain (C₄)

When this function is assigned to one of the flexible buttons, that button can turn on the Patch Chain function. The Patch Chain enables you to chain up to 10 different patch programs in sequence and recall them in the same sequence.

The Display shows **P0** first, and as you chain the patch program, changes like **P1** ~ **P9**.

Path Chain Programming

Each patch program in the Patch Chain can retain the following four messages. The program change number, however, can be left free for you to set the number you like later during live performance.

Program Change
MIDI Channel
MIDI Mode (OMNI ON/OFF, Poly/Mono)
Key Transpose

Up to 10 patches from P0 to P9 can be chained in the Patch Chain.

Operation

Assign any of the flexible buttons to the Patch Chain Button, as described in "d. Changing the functions of Button."

- ① Turn the Axis to the Write mode.
- ② Set the Program Change, MIDI Channel, MIDI Mode, Key Transpose to your taste.
- ③ Push the Patch Chain Button.

The Display shows the Patch Chain Program number 0.

- ④ While still holding the Patch Chain Button, push the Program Change Button ②.

Now, the setting you have made in step ② will be written in the patch chain program number 0 shown in the Display.

⑤ Release the program Change Button ③, and the patch chain program number 1 will appear in the Display, showing that it is ready to accept the messages.

⑥ Repeat the steps ② to ⑤ as many times as necessary.

Up to 10 patch programs (P0 to P9) can be written into the Patch Chain.

⑦ Return the Axis to the Play mode.

* The Axis can retain the Patch Chain data even if switched off. Initialization, however, clears the entire data.

Not to write Program Change message to Patch Chain:

Instead of writing Program Change number in the step ②, push any of the A₃, B₃ or C₃.

Calling the Patch Chain

Operation

① Press the Patch Chain Button, and Patch Chain Program 0 is called.

The Display shows **PO**.

② Release the Patch Chain Button.

The Display shows the program change number written in the Patch Chain program number 0.

③ Press the Patch Chain Button, and the next Patch Chain Program P1 will be called. Then keep on calling the rest of the Patch Chain. If you press the Patch Chain Button after the last patch chain program is called, the P0 will be recalled.


*** To call Patch Chain Program number 0 in the middle of calling Patch Chain, press the Program Change Button ③ then the Patch Chain Button.**

*** If there is no data written in the patch chain program, the Display will show **PE** (Program End) instead of the Patch Chain Program number.**

Application of Patch Chain

Patch Chain is the function that changes Program Change numbers, MIDI Channels, MIDI modes, and Key Transpose modes, therefore can be effectively used as follows.

MIDI Channel Selector



When using more than one MIDI Sound Module, assign P0 to MIDI channel 1 and P1 to channel 2. Then, pressing the Patch Chain Button alternately selects channel 1 and 2.

MIDI Mode Selector

Patch Chain function can be used for selecting Poly/Mono, and OMNI ON/OFF. (See page 29.)

Programmable Key Transposer

This can be effectively used for the music that includes transition, or octave transposition along with tone color change.

Editing a patch program in the Patch Chain

Operation

- ① Turn the Axis to the Write mode.
 - ② Set the Program Change number, MIDI Channel, MIDI Mode and Key Transpose as you desire.
 - ③ While holding the Patch Chain Button, call the Patch Program number where you wish to write the above setting, by using the F \sharp or G \sharp key.
- Each time G \sharp key is pressed, one Patch Chain Program number is advance. And pressing the F \sharp key backs up one number.
- ④ While still holding the Patch Chain Button, push the Program Change Button ③.
 - ⑤ Return the Axis to the Play mode.

Adding a Patch program to Patch Chain

Operation

- ① Turn the Axis to the Write mode.
- ② Set the Program Change number, MIDI Channel, MIDI Mode and Key Transpose as you desire.
- ③ Go to the Chain Program number following the entire existing Patch Chain data, by pressing the G \sharp Key while holding the Patch Chain Button.
- ④ While still holding the Patch Chain Button, push the Program Change Button ③.
- ⑤ Repeat the steps ② to ④ as many times as necessary.
- ⑥ Return the Axis to the Play mode.

Deleting from a patch program to the end of the Patch Chain

Operation


- ① Turn the Axis to the Write mode.
- ② While holding the Patch Chain Button, go to the patch chain program number from which to the end to be deleted (e.g. **PG**), by using the F₁ Key or G₁ key.
- ③ Press the A₁ key, while still holding the Patch Chain Button.
- ④ Return the Axis to the Play mode.

*** The A₁ Key always means the end of the Patch Chain data.**


7) Latch/Unlatch of the buttons

Unlatch or latch can be selected for the Octave Up Button **8**, Chord Memory Button **9** and Remote Switch Pedal **19**.

Latch : Each time you press the button, On and Off are alternately selected.



Unlatch : Just while the button is held down, it is on.



Right after the functions of a button are changed, the button is automatically set to unlatch.


How to set a button to latch

① Turn the Axis to the Write mode.

② Push the relevant button.

The indicator above the button flashes. (If the button has already been set to latch, the indicator remains lighted.)

③ While still holding the button, press the C3 key.



The indicator stops flashing and lights steadily, showing that it is now a latch button.

④ Return the Axis to the Play mode.

To change to unlatch button, you need to set the function of the button once again.

*** The Modulation Button ④ is a flexible button, but cannot be set to latch.**

*** When a button selects any of the following functions, it cannot be set to the latch button.**

- Increment
- Decrement
- Patch Chain

3 Functions

Each of the following functions can be turned on or off. And also, you can get the Display show the current condition.

	Key for Display	Key for ON/OFF
After Touch	G ₃	A ₃
Touch Hold	F ₃	G ₃
POLY/MONO	D ₃	E ₃
OMNI ON/OFF	C ₃	D ₃
Tune Request	C ₄	

a. How to get the Display show the current condition:

While holding the Function Button ❶ down, push the relevant Key for Display. (See the table above.)

While the Function Button ❶ is held down, the Display shows the current on/off condition of the function.

b. How to turn on or off the function


While holding the Function Button ❶ down, push the Key for ON/OFF. (See the table above.)

While the Function Button ❶ is held down, the Display shows the new On/Off condition.

c. Explanation on the Functions

1) After Touch

The After Touch message of the Axis can be sent by the Control Change number 1 or 3, as well as by the MIDI After Touch.

The Display will change like  the function is changed.

(Function 1)

After Touch message is sent by Control Change number 1.

(Function 2)

After Touch message is sent by MIDI After Touch.


(Function 3)

After Touch message is sent by Control Change number 3.

*** Even if the sound module you use cannot receive After Touch message, in other words, if it does not feature after touch function (such as Juno-106 or MKS-30), set the Function 1, and it will take on the modulation by the After Touch message of the Axis.**

2) Touch Hold

This is the function that retains the amount of the after touch obtained when the key is pushed most strongly. (This function is off in the Standard Setting.)

The Display changes like  , as the function is changed.

 (Hold) Touch Hold On

 (Normal) Touch Hold Off

*** The Touch Hold function is especially useful for the sound with a long release time, but if you push the key too hard, After Touch will affect the sound right from the beginning of a note, therefore the created sound will be unnatural.**

3) POLY/MONO

The Axis can send this message that determines whether the connected sound module is played in polyphonic or monophonic. (In the Standard Setting, this is set to POLY.)

*** If the sound module cannot receive this message, the message is ignored.**

The Display will act like  as the function is changed.

 (POLY) Polyphonic

 (Mono) Monophonic

4) OMNI ON/OFF

OMNI On/Off is the messages that determines whether the MIDI messages are received on all Channels or on the specific Channel. The Axis can send this message to the sound module.

The Display will act like  as the function is changed.

 (ON) OMNI ON


 (OFF) OMNI OFF

*** Even if the sound module is set to the OMNI ON mode, it may not receive messages (such as OMNI ON/OFF, Poly/Mono etc.) on the channel other than that of its own.**

5) Tune Request

This is the message that autotunes the sound module (receiver). This message can be sent in a simple way as follows.

While holding the Function Button , push the C₄ Key.

While the Function Button is held down, the Display shows  , showing that Tune Request message is being sent.

4 Appendix Table (1)

Standard Setting (= Setting obtained by Initialization)

MIDI Channel/Mode

MIDI Channel	1
OMNI	OFF
POLY/MONO	POLY

Functions of the Wheels and Buttons

	Function	Data Transmitted with MIDI
Modulation Wheel ⑥	Modulation	Control Change 1
Master Volume Wheel ⑦	Volume	Control Change 7
Modulation Button ④	Modulation (Rise Time Fast)	Control Change 1
Octave Up Button ⑧	Octave Up (Latch)	(Key numbers shifted)
Chord Memory Button ⑨	Chord Memory (Latch)	ON/OFF of the recorded key numbers
Remote Switch Pedal ⑱	Hold (Untatch)	Control Change 64

Other Data in Memory

Function	Condition
Key Transpose	C ₂ (No Transposition)
After Touch	Function 2 (Channel Pressure)
Touch Hold	OFF
Patch Chain	Not recorded
Chord Memory	Not recorded

Appendix Table (2) Key Assignment Table

	Program Change				Key Transpose		MIDI Channel Function	Write Mode	
	Block A	Block B	Block C	Block D	Block E	Display Value (from C2)		Button (Pedal)	Wheel
E ₀	11	41	71	21	51	-E	MIDI CH1	61 Hold	11
F ₀	12	42	72	22	52	-F	MIDI CH2	62 Portamento	12 Modulation
G ₀	13	43	73	23	53	-G	Initialization	63	2
A ₀	14	44	74	24	54	-A	MIDI CH3	64	3
B ₀	15	45	75	25	55	-B	MIDI CH4	65	4
C ₁	16	46	76	26	56	-C	MIDI CH5	66	5 Portamento Time
D ₁	17	47	77	27	57	-D	MIDI CH6	67	6 Volume
E ₁	18	48	78	28	58	-E	MIDI CH7	68	7
F ₁	21	51	81	31	61	-F	MIDI CH8	71	8
G ₁	22	52	82	32	62	-G	MIDI CH9	72	9
A ₁	23	53	83	33	63	-A	MIDI CH10	73	10
B ₁	24	54	84	34	64	-B	MIDI CH11	74	11
C ₂	25	55	85	35	65	-C	MIDI CH12	75	12
D ₂	26	56	86	36	66	-D	MIDI CH13	76	13
E ₂	27	57	87	37	67	-E	Write Mode Set/Reset	77	14
F ₂	28	58	88	38	68	-F	MIDI CH14	78	15
G ₂	31	61	91	41	71	-G	Write Mode Set/Reset	81	16
A ₂	32	62	92	42	72	-A	MIDI CH15	82	17
B ₂	33	63	93	43	73	-B	MIDI CH16	83	18
C ₃	34	64	94	44	74	-C	Chord Memory Write Mode	84	19
D ₃	35	65	95	45	75	-D	Chord Memory Write Mode	85	20
E ₃	36	66	96	46	76	-E	Chord Memory Write Mode	86	21
F ₃	37	67	97	47	77	-F	Chord Memory Write Mode	87	22
G ₃	38	68	98	48	78	-G	Chord Memory Write Mode	88	23
A ₃	39	69	99	49	79	-A	Chord Memory Write Mode	89	24
B ₃	40	70	100	50	80	-B	Chord Memory Write Mode	90	25
C ₄	41	71	101	51	81	-C	Chord Memory Write Mode	91	26
	42	72	102	52	82	-D	Chord Memory Write Mode	92	27
	43	73	103	53	83	-E	Chord Memory Write Mode	93	28
	44	74	104	54	84	-F	Chord Memory Write Mode	94	29
	45	75	105	55	85	-G	Chord Memory Write Mode	95	30
	46	76	106	56	86	-A	Chord Memory Write Mode	96	31
	47	77	107	57	87	-B	Chord Memory Write Mode	97	32
	48	78	108	58	88	-C	Chord Memory Write Mode	98	33
	49	79	109	59	89	-D	Chord Memory Write Mode	99	34
	50	80	110	60	90	-E	Chord Memory Write Mode	100	35
	51	81	111	61	91	-F	Chord Memory Write Mode	101	36
	52	82	112	62	92	-G	Chord Memory Write Mode	102	37
	53	83	113	63	93	-A	Chord Memory Write Mode	103	38
	54	84	114	64	94	-B	Chord Memory Write Mode	104	39
	55	85	115	65	95	-C	Chord Memory Write Mode	105	40
	56	86	116	66	96	-D	Chord Memory Write Mode	106	41
	57	87	117	67	97	-E	Chord Memory Write Mode	107	42
	58	88	118	68	98	-F	Chord Memory Write Mode	108	43
	59	89	119	69	99	-G	Chord Memory Write Mode	109	44
	60	90	120	70	100	-A	Chord Memory Write Mode	110	45
	61	91	121	71	101	-B	Chord Memory Write Mode	111	46
	62	92	122	72	102	-C	Chord Memory Write Mode	112	47
	63	93	123	73	103	-D	Chord Memory Write Mode	113	48
	64	94	124	74	104	-E	Chord Memory Write Mode	114	49
	65	95	125	75	105	-F	Chord Memory Write Mode	115	50
	66	96	126	76	106	-G	Chord Memory Write Mode	116	51
	67	97	127	77	107	-A	Chord Memory Write Mode	117	52
	68	98	128	78	108	-B	Chord Memory Write Mode	118	53
	69	99	129	79	109	-C	Chord Memory Write Mode	119	54
	70	100	130	80	110	-D	Chord Memory Write Mode	120	55
	71	101	131	81	111	-E	Chord Memory Write Mode	121	56
	72	102	132	82	112	-F	Chord Memory Write Mode	122	57
	73	103	133	83	113	-G	Chord Memory Write Mode	123	58
	74	104	134	84	114	-A	Chord Memory Write Mode	124	59
	75	105	135	85	115	-B	Chord Memory Write Mode	125	60
	76	106	136	86	116	-C	Chord Memory Write Mode	126	61
	77	107	137	87	117	-D	Chord Memory Write Mode	127	62
	78	108	138	88	118	-E	Chord Memory Write Mode	128	63
	79	109	139	89	119	-F	Chord Memory Write Mode	129	64
	80	110	140	90	120	-G	Chord Memory Write Mode	130	65
	81	111	141	91	121	-A	Chord Memory Write Mode	131	66
	82	112	142	92	122	-B	Chord Memory Write Mode	132	67
	83	113	143	93	123	-C	Chord Memory Write Mode	133	68
	84	114	144	94	124	-D	Chord Memory Write Mode	134	69
	85	115	145	95	125	-E	Chord Memory Write Mode	135	70
	86	116	146	96	126	-F	Chord Memory Write Mode	136	71
	87	117	147	97	127	-G	Chord Memory Write Mode	137	72
	88	118	148	98	128	-A	Chord Memory Write Mode	138	73
	89	119	149	99	129	-B	Chord Memory Write Mode	139	74
	90	120	150	100	130	-C	Chord Memory Write Mode	140	75
	91	121	151	101	131	-D	Chord Memory Write Mode	141	76
	92	122	152	102	132	-E	Chord Memory Write Mode	142	77
	93	123	153	103	133	-F	Chord Memory Write Mode	143	78
	94	124	154	104	134	-G	Chord Memory Write Mode	144	79
	95	125	155	105	135	-A	Chord Memory Write Mode	145	80
	96	126	156	106	136	-B	Chord Memory Write Mode	146	81
	97	127	157	107	137	-C	Chord Memory Write Mode	147	82
	98	128	158	108	138	-D	Chord Memory Write Mode	148	83
	99	129	159	109	139	-E	Chord Memory Write Mode	149	84
	100	130	160	110	140	-F	Chord Memory Write Mode	150	85
	101	131	161	111	141	-G	Chord Memory Write Mode	151	86
	102	132	162	112	142	-A	Chord Memory Write Mode	152	87
	103	133	163	113	143	-B	Chord Memory Write Mode	153	88
	104	134	164	114	144	-C	Chord Memory Write Mode	154	89
	105	135	165	115	145	-D	Chord Memory Write Mode	155	90
	106	136	166	116	146	-E	Chord Memory Write Mode	156	91
	107	137	167	117	147	-F	Chord Memory Write Mode	157	92
	108	138	168	118	148	-G	Chord Memory Write Mode	158	93
	109	139	169	119	149	-A	Chord Memory Write Mode	159	94
	110	140	170	120	150	-B	Chord Memory Write Mode	160	95
	111	141	171	121	151	-C	Chord Memory Write Mode	161	96
	112	142	172	122	152	-D	Chord Memory Write Mode	162	97
	113	143	173	123	153	-E	Chord Memory Write Mode	163	98
	114	144	174	124	154	-F	Chord Memory Write Mode	164	99
	115	145	175	125	155	-G	Chord Memory Write Mode	165	100
	116	146	176	126	156	-A	Chord Memory Write Mode	166	101
	117	147	177	127	157	-B	Chord Memory Write Mode	167	102
	118	148	178	128	158	-C	Chord Memory Write Mode	168	103
	119	149	179	129	159	-D	Chord Memory Write Mode	169	104
	120	150	180	130	160	-E	Chord Memory Write Mode	170	105
	121	151	181	131	161	-F	Chord Memory Write Mode	171	106
	122	152	182	132	162	-G	Chord Memory Write Mode	172	107
	123	153	183	133	163	-A	Chord Memory Write Mode	173	108
	124	154	184	134	164	-B	Chord Memory Write Mode	174	109
	125	155	185	135	165	-C	Chord Memory Write Mode	175	110
	126	156	186	136	166	-D	Chord Memory Write Mode	176	111
	127	157	187	137	167	-E	Chord Memory Write Mode	177	112
	128	158	188	138	168	-F	Chord Memory Write Mode	178	113
	129	159	189	139	169	-G	Chord Memory Write Mode	179	114
	130	160	190	140	170	-A	Chord Memory Write Mode	180	115
	131	161	191	141	171	-B	Chord Memory Write Mode	181	116
	132	162	192	142	172	-C	Chord Memory Write Mode	182	117
	133	163	193	143	173	-D	Chord Memory Write Mode	183	118
	134	164	194	144	174	-E	Chord Memory Write Mode	184	119
	135	165	195	145	175	-F	Chord Memory Write Mode	185	120
	136	166	196	146	176	-G	Chord Memory Write Mode	186	121
	137	167	197	147	177	-A	Chord Memory Write Mode	187	122
	138	168	198	148	178	-B	Chord Memory Write Mode	188	123
	139	169	199	149	179	-C	Chord Memory Write Mode	189	124
	140	170	200	150	180	-D	Chord Memory Write Mode	190	125
	141	171	201	151	181	-E	Chord Memory Write Mode	191	126
	142	172	202	152	182	-F	Chord Memory Write Mode	192	127
	143	173	203	153	183	-G	Chord Memory Write Mode	193	128
	144	174	204	154	184	-A	Chord Memory Write Mode	194	129
	145	175	205	155	185	-B	Chord Memory Write Mode	195	130
	146	176	206	156	186	-C	Chord Memory Write Mode	196	131
	147	177	207	157	187	-D	Chord Memory Write Mode	197	132
	148	178	208	158	188	-E	Chord Memory Write Mode	198	133
	149	179	209	159	189	-F	Chord Memory Write Mode	199	134
	150	180	210	160	190	-G	Chord Memory Write Mode	200	135
	151	181	211	161	191	-A	Chord Memory Write Mode	201	136
	152	182	212	162	192	-B	Chord Memory Write Mode	202	137
	153	183	213	163	193	-C	Chord Memory Write Mode	203	138
	154	184	214	164	194	-D	Chord Memory Write Mode	204	139
	155	185	215	165	195	-E	Chord Memory Write Mode	205	140
	156	186	216	166	196	-F	Chord Memory Write Mode	206	141
	157	187	217	167	197	-G	Chord Memory Write Mode	207	142
	158	188	218	168	198	-A	Chord Memory Write Mode	208	143
	159	189	219	169	199	-B	Chord Memory Write Mode	209	144
	160	190	220	170	200	-C	Chord Memory Write Mode	210	145
	161	191	221	171	201	-D	Chord Memory Write Mode	211	146
	162	192	222	172	202	-E	Chord Memory Write Mode	212	147
	163	193	223	173	203	-F	Chord Memory Write Mode	213	148
	164	194	224	174	204	-G	Chord Memory Write Mode	214	149
	165	195	225	175	205	-A			

5 Specifications

AXIS-1 • MIDI Keyboard

Control Unit

- **Keyboard** 45 keys, 3 $\frac{3}{4}$ Octaves
- **Buttons** MIDI Channel/Function Button
Key Transpose Button
Program Change Button
Chord Memory Button (Flexible)
Octave Up Button (Flexible)
Modulation Button (Flexible)
- **Wheels** Master Volume Wheel (Flexible)
Modulation Wheel (Flexible)
Pitch Bender
- **Display** Display Window (2 figures)
Octave Up Indicator
Chord Memory Indicator
Hold Indicator
- **Output**
Cable Connector
- **Dimensions**
1075 (W) × 220 (D) × 63 (H) mm/
42 $\frac{5}{16}$ " × 8 $\frac{1}{16}$ " × 2 $\frac{1}{2}$ "
- **Weight** 3.5 kg/7lb 11 oz

Power Supply Unit

- **Pedal**
Remote Switch Pedal (Hold Pedal, Flexible)
- **Display**
MIDI OUT Indicator
Power Indicator
- **Rear Panel**
Cable Connector
MIDI OUT Connector (5P-DIN)
Power Switch
- **Consumption**
6W
- **Dimensions**
211 (W) × 141 (D) × 61 (H) mm/
8 $\frac{5}{16}$ " × 5 $\frac{9}{16}$ " × 2 $\frac{3}{8}$ "
- **Weight** 1 kg/2lb 3oz
- **Accessories**
Cable (8m) × 1
MIDI Cable (5m) × 1

Options

- Carrying Case** SC-1
MIDI/SYNC Cable MSC-25/50

MODEL **AXIS-1** MIDI Implementation Chart

Function.....		Transmitted			Recognized	Remarks
		1	2	3		
Basic Channel	Default	1 - 16			×	Memorized
	Changed	1 - 16			×	
Mode	Default	1 - 4			×	Memorized
	Messages	OMNI on off, POLY MONO			×	
	Altered	*****			×	
Note Number	True voice	0 - 127			×	
		*****			×	
Velocity	Note ON	○ 9n, v=1-127			×	
	Note OFF	× 9n, v=0			×	
After Touch	Key's	×	×	×	×	
	Ch's	×	○	×	×	
Pitch Bender		○	○	○	×	
Control Change	1- 31	○	○	○	×	
	32- 63	×	×	×	×	
	64- 95	○	○	○	×	
	96-121	×	×	×	×	
Prog Change	True #	○	○	○	×	0 - 119
		*****			×	
System Exclusive		×	×	○	×	\$F0, 43, F7 for old MIDI
System Common	Song Pos	×	×	×	×	
	Song Sel	×	×	×	×	
	Tune	○	○	○	×	
System Real Time	Clock	×	×	×	×	
	Commands	×	×	×	×	
Aux	Local ON · OFF	×	×	×	×	
	All Notes OFF	○	○	○	×	
Mes-sages	Active Sense	○	○	×	×	
	Reset	×	×	×	×	
Notes		Function : After Touch Function On power-up : Transmit memorized mode to memorized ch.				

Mode 1 : OMNI ON, POLY
Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON, MONO
Mode 4 : OMNI OFF, MONO

○ : Yes
× : No

MIDI Keyboard

MODEL **AXIS-1** MIDI Implementation

1. TRANSMITTED DATA			
Status	Second	Third	Description
1001 nnnn	0kkk kkkk	0000 0000	Note OFF #1
1001 nnnn	0kkk kkkk	0vvv vvvv	Note ON #1
1011 nnnn	0ccc cccc	0vvv vvvv	Control Change #2
1011 nnnn	0111 1011	0000 0000	ALL NOTE OFF
1011 nnnn	0111 1100	0000 0000	OMNI OFF
1011 nnnn	0111 1101	0000 0000	OMNI ON
1011 nnnn	0111 1110	0000 0001	MONO ON
1011 nnnn	0111 1111	0000 0000	POLY ON
1100 nnnn	0ppp pppp		Program Change #3
1110 nnnn	0vvv vvvv	0vvv vvvv	Pitch Bender Change
1111 0110			Tune Request
1101 nnnn	0vvv vvvv		Channel Pressure #4
1011 nnnn	0000 0001	0vvv vvvv	#5
1011 nnnn	0000 0011	0vvv vvvv	#6
1111 0000	0100 0011		Exclusive Message #7
	1111 0111 (EOX)		(Active Sensing)
1111 1110			Active Sensing #8

Notes : #1 kkkkkk = 0 through 127
#2 ccccccc = 0 through 31
vvvvvvv = 0 through 127
ccccccc = 64 through 95
vvvvvvv = 0 or 127
0 : OFF
127 : ON
#3 ppppppp = 0 through 119
#4, #5, #6, #7, #8
Data format of "After Touch(#4, #5, #6)" and "Active Sensing(#7, #8)"
are chosen by "After Touch Function".

After Touch Function	After Touch	Active Sensing
1	#5	#8
2	#4	#8
3	#6	#7

UPC

17049587



10981